

FIRE and evacuation procedure iNANO buildings (1590-1593)

At iNANO there is both an automatic fire alarm system and a voice alarm system, which is activated by the automatic fire alarm system

ACTIVATE THE RED ALARM BUTTONS

(Only if there is a fire or other circumstances arise which requires evacuation and the voice alarm system does NOT sound)

GO TO THE NEAREST EVACUATION EQUIPMENT

(See picture on opposite side: FOLLOW THE INSTRUCTIONS FOR EVACUATION. More details are found in the flyer "Evacuation at Aarhus University" and by the evacuation equipment).)

SAVE PEOPLE IN DANGER (if safe)

EVACUATE THE BUILDINGS:

Use nearest *safe* escape route. Escape route signs look like this:

It is *not* allowed to use the elevators.

Go to the Emergency Assembly Point. See location on opposite side.



DIAL 1-1-2 (when you activate the red alarm boxes you MUST always dial 1-1-2)

MEET THE FIRE DEPARTMENT AND INFORM THEM:

Are there people in the buildings? Where?

What caused the evacuation/Where is the problem?

AT THE EMERGENCY ASSEMBLY POINT:

Inform the permanent staff (if any is present) that you are there (VIP/TAP)

Point out if you know someone is missing from the buildings

Stay at the Emergency Assembly point until the fire fighters give other instructions

CALL 87 15 16 17

(AU's own alarm number – if possible have someone from the permanent staff VIP/TAP make this call)

NOTE: Access to the laboratories is not allowed until 30 minutes after ventilation has been restored!

(Ventilation is restored only after the alarms in the labs have been deactivated. If in doubt ask the permanent staff)

Emergency Assembly & Evacuation equipment

